

Ch.4 Plane truss element for large displacements and rotations

For trusses with a *constant value of strain* along their length, their FEM formulation is relatively simple because it is not necessary to express the displacement or deformation of a general point of the element. In such a case, the value of the deformation can be expressed using the coordinates and displacements of the end points of an element. We will document this by creating matrices of a plane element suitable for solving problems with large displacements, rotations, and *small deformations*. We will use Green's strain for the deformation of the element and perform the integration of the internal energy of the element on the initial volume of the element. Such a formulation, in which the sought values are expressed using the initial configuration of the body (element), is called *the total Lagrangian formulation*. The choice of Green's strain simplifies the formulation to such an extent that all members of the element's basic matrices can be expressed explicitly using the general parameters of the element.




Fig. 4.1

Let us consider an arbitrary element cut out close to the nodes by an imaginary section from a plane truss structure, which in the unloaded state is located in the *reference* position C_0 (Fig. 4.1) determined by the coordinates of the points i and j . After loading, the element reaches the *actual* position C_1 and the components of the end point displacements that arise during this displacement are arranged in the vector

$$\mathbf{u}_e = [u_i \quad v_i \quad u_j \quad v_j]^T \quad (4.1)$$

From the change in the length of the element, Green's strain at its current position can be expressed as follows:

$$\varepsilon_G = \frac{l^2 - l_0^2}{2l_0^2} \quad (4.2)$$

If we introduce $X_{ji} = X_j - X_i, Y_{ji} = Y_j - Y_i, u_{ji} = u_j - u_i, v_{ji} = v_j - v_i$, then for the squares of lengths we have

$$l_0^2 = X_{ji}^2 + Y_{ji}^2$$

$$l^2 = (X_{ji} + u_{ji})^2 + (Y_{ji} + v_{ji})^2$$

and according for Green's strain of the element we get

$$\varepsilon_G = \frac{1}{2l_0^2} (u_{ji}^2 + v_{ji}^2 + 2X_{ji}u_{ji} + 2Y_{ji}v_{ji}) \quad (4.3)$$

The strain energy of the element is

$$U_e = \frac{1}{2} \int_{V_0} \varepsilon_G \sigma_G dV_0 = \frac{1}{2} \int_0^{l_0} \varepsilon_G E_0 \varepsilon_G S_0 dx = \frac{1}{2} E_0 S_0 l_0 \varepsilon_G^2 \quad (4.4)$$

The displacement of the element associated with its axial deformation will cause forces, the components of which are arranged into a vector

$$\mathbf{q}_e = [Q_{iX} \quad Q_{iY} \quad Q_{jX} \quad Q_{jY}]^T \quad (4.5)$$

The element equilibrium condition requires a minimum value of the strain energy, so that

$$\mathbf{q}_e = \frac{\partial U_e}{\partial \mathbf{u}_e} = E_0 S_0 l_0 \varepsilon_G \frac{\partial \varepsilon_G}{\partial \mathbf{u}_e} \quad (4.6)$$

The expression $\partial \varepsilon_G / \partial \mathbf{u}_e$ in (4.6) is a vector whose terms are obtained by successive differentiation (4.3) with respect to the components of vector (4.1)

$$\frac{\partial \varepsilon_G}{\partial \mathbf{u}_e} = \frac{1}{l_0} [-k_X \quad -k_Y \quad k_X \quad k_Y]^T = \mathbf{b}_e \quad (4.7)$$

where

$$k_X = (X_{ji} + u_{ji}) / l_0 \quad \text{and} \quad k_Y = (Y_{ji} + v_{ji}) / l_0.$$

From the relation (4.6), we can now determine the components of the element's end forces corresponding to the specified displacements.

$$\mathbf{q}_e = N_G [-k_X \quad -k_Y \quad k_X \quad k_Y]^T \quad (4.8)$$

where the Green's force of the element is

$$N_G = S_0 \sigma_G = E_0 S_0 \varepsilon_G \quad (4.9)$$

The relation (4.8) gives the dependence between the components of the nodal displacements of the element \mathbf{u}_e and the components of the internal nodal forces of the element contained in vector \mathbf{q}_e . This relationship is nonlinear, unlike linear elements, but its meaning is the same in both cases: if we choose or calculate the displacements of the nodal elements of the element, we can determine the force load of the element at these displacements.

Green's stress is not identical to the axial stress, and Green's force is not identical to the axial force of the element. For an element with small deformations ($l \approx l_0$), the differences are negligible. Using the derived relations, these differences can be easily demonstrated for the case of axial tension of the element without a rotation. Consider the element in Fig. 4.1 in a horizontal position with node coordinates $X_i = Y_i = Y_j = 0, X_j = l_0$ with a single degree of freedom u_j ($u_i = v_i = v_j = 0$) and stretch it by the value $u_j = \Delta l$. According to (4.8), then for the component Q_{jX} , which in this case represents the axial force of the element, we obtain

$$Q_{jX} = N_G \frac{l_0 + \Delta l}{l_0} = N_G \frac{l}{l_0}$$

The vector of internal nodal forces allows, according to (3.16) and (4.6), to determine the tangential stiffness matrix of the element as follows:

$$\mathbf{K}_T^e = \frac{\partial \mathbf{q}_e}{\partial \mathbf{u}_e} = E_0 S_0 l_0 \frac{\partial \varepsilon_G}{\partial \mathbf{u}_e} \left(\frac{\partial \varepsilon_G}{\partial \mathbf{u}_e} \right)^T + E_0 S_0 l_0 \varepsilon_G \frac{\partial}{\partial \mathbf{u}_e} \left(\frac{\partial \varepsilon_G}{\partial \mathbf{u}_e} \right)^T = \mathbf{K}_M^e + \mathbf{K}_G^e \quad (4.10)$$

where for the so-called *material stiffness matrix of the element* we get

$$\mathbf{K}_M^e = E_0 S_0 l_0 \mathbf{b}_e \mathbf{b}_e^T = \frac{E_0 S_0}{l_0} \begin{bmatrix} k_X^2 & k_X k_Y & -k_X^2 & -k_X k_Y \\ k_X k_Y & k_Y^2 & -k_X k_Y & -k_Y^2 \\ -k_X^2 & -k_X k_Y & k_X^2 & k_X k_Y \\ -k_X k_Y & -k_Y^2 & k_X k_Y & k_Y^2 \end{bmatrix} \quad (4.11)$$

The *geometric stiffness matrix of the element* (initial stress matrix) is obtained by (4.10) and (4.7), where each term of the vector \mathbf{b}_e^T is derived with respect to all four terms of the vector \mathbf{u}_e

$$\mathbf{K}_G^e = \frac{N_G}{l_0} \begin{bmatrix} 1 & 0 & -1 & 0 \\ 0 & 1 & 0 & -1 \\ -1 & 0 & 1 & 0 \\ 0 & -1 & 0 & 1 \end{bmatrix} \quad (4.12)$$

From the relations (4.6) and (4.10), we can express the vector \mathbf{q}_e and tangential stiffness matrix of the element \mathbf{K}_T^e for any measure of deformation when we replace the strain ε_G in these relations with it. The formulation for the engineering strain with the correct constitutive relation $\sigma_{ing} = E_0 \varepsilon_{ing}$ is particularly interesting because the elastic modulus of the material is determined at this measure. True, we lose the simplicity that the Green's strain of deformation of the member provides when deriving the vector of internal nodal forces of the element and the tangential stiffness matrix. Now it holds

$$\varepsilon_{ing} = \frac{l - l_0}{l_0} = \frac{\sqrt{(X_{ji} + u_{ji})^2 + (Y_{ji} + v_{ji})^2} - \sqrt{X_{ji}^2 + Y_{ji}^2}}{\sqrt{X_{ji}^2 + Y_{ji}^2}} \quad (4.13)$$

and general vector terms

$$(\mathbf{b}_e)_{ing} = \frac{\partial \varepsilon_{ing}}{\partial \mathbf{u}_e} \quad (4.14)$$

are also not simple. However, the Mathematica program performs the necessary derivatives without any problems, and determining the necessary element matrices is easy (Example 4.3).

A plane truss element can also be considered a simple body that has 4 degrees of freedom in the plane. If we remove three degrees of freedom from it, we obtain a statically determinate strength problem with one unknown – the corresponding free component of the node displacement. The properties of the nodal force vector and tangential stiffness matrix of the element can be clearly demonstrated using examples of such a body.

Example 4.1

Using the derived relations, the axial force, stress, and nodal force vector for the element given in Figure 4.2 are calculated in the case that it rotates by an angle of 90° and stretches by 0.1 mm at node j under load.




Fig. 4.2

The position of the element is determined by the coordinates of the nodal points $X_i = Y_i = Y_j = 0$, $Y_j = 1000 \text{ mm}$. And the load is caused by the displacements $u_i = 0$, $v_i = 0$, $u_j = -1000$, $v_j = 1000.1 \text{ mm}$. The solution of the problem and the results are shown in Fig. 4.3.

```

E0 = 200 000 ; S0 = 100 ;
xi = 0 ; yi = 0 ; xj = 1000 ; yj = 0 ; ui = 0 ; vi = 0 ; uj = -1000 ; vj = 1000.1 ;
xji = xj - xi ; yji = yj - yi ; uji = uj - ui ; vji = vj - vi ;
L2 = (xji + uji) ^ 2 + (yji + vji) ^ 2 ; L = Sqrt[L2] ;
L02 = xji ^ 2 + yji ^ 2 ; L0 = Sqrt[L02] ;
epsG = (L2 - L02) / (2 * L02) ;
kx = (xji + uji) / L0 ; ky = (yji + vji) / L0 ;
Ng = E0 * epsG * S0 ;
Sig = Ng / S0 ;
q = Ng * {-kx, -ky, kx, ky} ;
Print["Axial force = ", Ng // N] ;
Print["Stress = ", Sig // N] ;
Print["Vector q= ", MatrixForm[q // N]] ;

Axial force = 2000.1
Stress = 20.001
Vector q=  $\begin{pmatrix} 0. \\ -2000.3 \\ 0. \\ 2000.3 \end{pmatrix}$ 

```

Fig. 4.3

Example 4.2

Solve Example 4.1 with the engineering strain.

```

Clear[ui, vi, uj, vj];
E0 = 200 000; S0 = 100;
xi = 0; yi = 0; xj = 1000; yj = 0;
xji = xj - xi; yji = yj - yi; uji = uj - ui; vji = vj - vi;
L2 = (xji + uji)^2 + (yji + vji)^2; L = Sqrt[L2];
L02 = xji^2 + yji^2; L0 = Sqrt[L02];
epsi = (L - L0) / L0;
Ni = E0 * epsi * S0;
Qi = {D[epsi, ui], D[epsi, vi], D[epsi, uj], D[epsi, vj]} * Ni * L0;
ui = 0; vi = 0; uj = -1000; vj = 1000.1;
Print[" Axial force = ", Ni // N];
Print[" Stress= ", Ni / S0 // N];
Print[" Vector q= ", MatrixForm[Qi // N]];

Axial force = 2000.
Stress= 20.
Vector q=  $\begin{pmatrix} 0. \\ -2000. \\ 0. \\ 2000. \end{pmatrix}$ 

```

Fig. 4.4

The solution is shown in Fig. 4.4. The force and stress results already correspond to the experience with the engineering strain scale:

$$N_{ing} = E_0 \Delta l_0 S_0 / l_0 = 200000 \cdot 0,1 \cdot 100 / 1000 = 2000 \text{ N}$$

The physical meaning of the tangential stiffness matrix is the same as that in the linear problem: it expresses the stiffness of an element in a loaded computational model of a structure (body) in the equilibrium state. The larger the numerical value of its members, the stiffer the element, and vice versa. The tangential attribute only states that, unlike in the linear problem, it changes during loading depending on the changing displacements and rotations of the element. In the final (equilibrium) state, *the material stiffness matrix* represents the standard stiffness matrix known from the linear problem, although the iterative process must determine the position of the element relative to the global coordinate system. (There were no problems with this in the linear problem because the position of the loaded element was identified with the initial position.) This can be documented by introducing the allowed simplification $l \approx l_0$ for this element. According to Fig. 4.1, we can introduce the following equation:

$$k_X = (X_{ji} + u_{ji}) / l_0 = \cos \beta, k_Y = (Y_{ji} + v_{ji}) / l_0 = \sin \beta$$

and the material matrix (4.11) of the element can be rewritten as

$$\mathbf{K}_M^e = \frac{E_0 S_0}{l_0} \begin{bmatrix} \cos^2 \beta & \sin \beta \cos \beta & -\cos^2 \beta & -\sin \beta \cos \beta \\ & \sin^2 \beta & -\sin \beta \cos \beta & -\sin^2 \beta \\ SYM & & \cos^2 \beta & \sin \beta \cos \beta \\ & & & \sin^2 \beta \end{bmatrix} \quad (4.15)$$

which is the standard stiffness matrix of a plane element at a given position relative to the global coordinate system. Therefore, the material matrix of a nonlinear element expresses the stiffness of the element resulting from its material and dimensional stiffness and its position in the loaded structure. It

also follows from (4.15) that during the translational movement of the element, its stiffness matrix does not change.

In the linear calculation, we neglect the effect of displacements of nodal points on the material stiffness of the element, and in (4.15) holds (Fig. 4.1).

$$k_X = X_{ji} / l_0 = \cos \delta, k_Y = Y_{ji} / l_0 = \sin \delta$$

The geometric matrix of an element (4.12) affects the stiffness of the element depending on the stress acting on the element; therefore, it is often called the *stress stiffness matrix*. In our case, the size of the members is influenced by the size of the axial force and, therefore, by the axial stress of the element. This matrix plays an important role in the analysis of the loss of stability, effect of stress on the bending stiffness, and change in the dynamic properties of the structure. We analyze its function using a *beam* nonlinear element in Chapter 6.